

**Installation position of gear selector mechanism**

**- A -Gear change cable**

**- B -Gate selector cable**

**- C -Heat shield**

◆ Holds selector cables in position

◆ Remove before removing the gear selector mechanism.

Double headed arrow -A- Gear selection movement

Double headed arrow -B- Gate selection movement

**1 - Gear selector lever**

**2 - Relay lever with actuating arm/gate selector cable**

- I -Removing and installing gear selector control cables =>  
Page [34-4](#)


- II -Removing and installing gear stick housing => Page  
[34-10](#)

- III -Removing and installing gear lever => Page [34-14](#)


- Before removing the gear selector mechanism, remove the  
following components:

- ◆ Catalyst
- ◆ Heat shield for selector cables => Page [34-1](#)


**II**



**I**




**III**



N34 - 0040


**II**




**Notes:** GM

- ◆ Before working on the selector change mechanism, disconnect earth strap from the battery in the engine compartment.
- ◆ Note radio code on vehicles with coded radio.
- ◆ To replace the selector cables remove gear selector mechanism complete.
- ◆ Do not kink selector cables.
- ◆ Lubricate all mountings and contact surfaces with MoS2 grease.
- ◆ Adjusting selector cables  
=> Page [34-19](#)

**I**



**III**



N34 - 0040