

Gear oil specification => Page 00-3

⇦ - Remove plug (arrow) to check oil

The oil level is correct when the rear final drive is filled to the lower edge of the filler hole.

- Fit plug (arrow).

When filling with new oil note following:

- Remove bolt (arrow).

- Top up oil to lower edge of filler hole.

- Fit plug (arrow).