

Dismantling and assembling sequence

=> Page 34-89

I - Removing and installing cover for gearbox housing and 5th gear **=> Page** 34-82

II - Dismantling and assembling gearbox housing and shift mechanism **=> Page** 34-85

III - Dismantling and assembling input shaft, output shaft, differential and selector forks **=> Page** 34-87