Removing

- Removing over-centre spring => Page 30-5.

- Separate clutch pedal from master cylinder => Page 30-12and push operating rod towards engine compartment onto stop.

- Remove clutch pedal securing clip from pivot pin, by levering tab up with a screwdriver and pushing clip off.

- Drive pivot pin out with drift.

- Take out clutch pedal.

Installing

Installation is carried out in the reverse sequence.