

Removing

- Remove coolant expansion tank and lay to one side.

Note:

Do not open cooling system.

- Pull supply hose off brake fluid reservoir and seal.

- Remove pipe from master cylinder and seal.

⇦ Separate master cylinder operating rod from clutch pedal as follows:

- Insert uncoupling tool 3318 in the clutch pedal cut-out (arrow A). The inscription "top/oben" (arrow B) points towards dash panel.

- Press uncoupling clamp together with pliers.

- Unbolt master cylinder from engine compartment.

Installing



Installation is carried out in the reverse sequence, when doing this note the following:

⇦ - The retainer -A- must be fitted to the master cylinder operating rod -B-.

- To engage press clutch pedal towards bulkhead (direction of arrow). Ensure correctly located.

- Bleeding clutch system after installing master cylinder=>Page 30-14.