

Note:

Gearbox and bevel box are filled together through the oil filler hole in the gearbox.

Gear oil specification => Page 00-3

⇦ - Remove plug (arrow) to check oil

The oil level is correct when the gearbox is full to the lower edge of the filler hole.

- Fit plug (arrow).

When filling with new oil note following:

- Remove bolt (arrow).
- Top up oil to lower edge of filler hole.
- Fit plug (arrow).
- Start engine, engage gear and allow gearbox to turn for approx. 2 minutes.
- Stop engine and remove plug (arrow).
- Top up oil to lower edge of filler hole again.
- Fit plug (arrow).