Removing and installing viscous coupling oil seal in rear final drive (final drive installed)



Removing

- Removing viscous coupling => Page 39-96.

- Pull seal out with VW 681.

Installing

⇦ - Drive new seal onto stop.

- Fill gap between sealing and dust lips with multi-purpose grease.

- Install viscous coupling.

- Checking rear final drive oil
  => Page 39-111.