Position of shims



- S1 -Ring nut screwed in depth

- S2 -Shim for bevel gear

- S3 -Shim for shaft bevel gear

-