

Removing

- Remove driver's side lower left shelf

=> General body repairs; Repair group 70; Removing and installing dash panel=>

⇦ - Tension over-centre spring with clutch pedal and fit retaining clamp 3317 from above.

Note:

The drilling (arrow) faces towards clutch pedal.

- Bring clutch pedal to rest position and take out over-centre spring together with retaining clamp 3317.



- Operate clutch pedal.

⇦ - First insert over-centre spring in position (arrow A), then lower vertically until the retaining clamp seats on the mounting lug of the clutch pedal (arrow B).

- Take out retaining clamp whilst bringing clutch pedal to rest position.